


Fascia Configuration
FFTT1

Pre-bored hole positions to use for
FFTT1 Fridge/Freezer Ends




All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly

- Red = Pre-Bored holes to use for Fixed shelves
- Orange = Additional Pre-Bored holes required for fixed shelves
- Green = Pre-Bored holes to use for Hinge Plates
- Lilac = Additional holes required for Hinge Plates

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS **FFTT1** FRIDGE/FREEZER

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.



Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjoplc.com
view details in Support


Fascia Configuration
FFTT2

Pre-bored hole positions to use for
FFTT2 Fridge/Freezer Ends

AVALON TALL HEIGHT


DRILLING POSITIONS FOR DOORS **FFTT2** FRIDGE/FREEZER

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.



All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly

Red = Pre-Bored holes to use for Fixed shelves
Green = Pre-Bored holes to use for Hinge Plates
Lilac = Additional holes required for Hinge Plates



Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjopl.com
view details in Support


Fascia Configuration
Larder available in
300/400/500/600 widths

Pre-bored hole positions to use for
Tall Larder Ends

AVALON TALL HEIGHT


DRILLING POSITIONS FOR DOORS LARDER ENDS

Illustrated below are the Door & Drawer options for
Oven Housings and Larder Ends.
We recommend prior to the assembly of
 housings the installer makes themselves familiar with the
 door/drawer configuration they are to install.
 This should alleviate any misalignment which could occur if
 the installer does not read and digest the diagrams opposite
 which clearly illustrate the correct positions of all door and
 drawer configurations.



Please note that many integrated appliances now require
very specific drilling to suit their unique hinges, doors
should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjopl.com
view details in Support




All positions shown are taken from 0.0 and should be reduced in
accordance with any scribing, or marked up prior to assembly

Red = Pre-Bored holes to use for Fixed shelves
Green = Pre-Bored holes to use for Hinge Plates

Fascia Configuration
TT3 Oven Housing

Pre-bored hole positions to use for
TT3 Oven Ends



All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly


Red = Pre-Bored holes to use for Fixed shelves
Green = Pre-Bored holes to use for Hinge Plates

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS TT3 OVEN HOUSING 890mm Nominal Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.

Door & Unit Sizes.
Tall Housing Heights Configuration. 2317mm (Max ht).




Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:

www.jjopl.com
view details in Support

Fascia Configuration
TT4 Oven Housing

Pre-bored hole positions to use for
TT4 Oven Ends



All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly


Red = Pre-bored holes to use for Fixed shelves
Green = Pre-bored holes to use for Hinge Plates
Blue = Additional holes required for Drawer Runners

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS TT4 OVEN HOUSING 890mm Nominal Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.

Door & Unit Sizes.
Tall Housing Heights Configuration. 2317mm (Max ht).




Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjoplc.com
view details in Support

Fascia Configuration
TT5 Oven Housing

Pre-bored hole positions to use for
TT5 Oven Ends



All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly


Red = Pre-bored holes to use for Fixed shelves
Green = Pre-bored holes to use for Hinge Plates
Blue = Additional holes required for Drawer Runners

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS TT5 OVEN HOUSING 890mm Nominal Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.

Door & Unit Sizes.
Tall Housing Heights Configuration. 2317mm (Max ht).




Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjopl.com
view details in Support

Fascia Configuration
TT6 Oven Housing

Pre-bored hole positions to use for
TT6 Oven Ends



All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly


Red = Pre-bored holes to use for Fixed shelves
Green = Pre-bored holes to use for Hinge Plates
Blue = Additional holes required for Drawer Runners

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS TT6 OVEN HOUSING 890mm Nominal Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.

Door & Unit Sizes.
Tall Housing Heights Configuration. 2317mm (Max ht).




Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:

www.jjopl.com
view details in Support

Fascia Configuration
TT1 Oven Housing

Pre-bored hole positions to use for
TT1 Oven Ends




All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly

- Red = Pre-Bored holes to use for Fixed shelves
- Orange = Additional Pre-Bored holes required for fixed shelves
- Green = Pre-Bored holes to use for Hinge Plates
- Blue = Additional holes required for Drawer Runners
- Lilac = Additional holes required for Hinge Plates

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS TT1 OVEN HOUSING 600mm Nominal Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.




Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjoplc.com
view details in Support

**Fascia Configuration
TT2 Oven Housing**

**Pre-bored hole positions to use for
TT2 Oven Ends**




All positions shown are taken from 0.0 and should be reduced in accordance with any scribing, or marked up prior to assembly

- Red = Pre-Bored holes to use for Fixed shelves
- Orange = Additional Pre-Bored holes required for fixed shelves
- Green = Pre-Bored holes to use for Hinge Plates
- Blue = Additional holes required for Drawer Runners
- Lilac = Additional holes required for Hinge Plates

AVALON TALL HEIGHT

DRILLING POSITIONS FOR DOORS & DRAWERS TT2 OVEN HOUSING 600mm Nominal Aperture Size/ 450mm Nominal M/Wave Aperture Size

Illustrated below are the Door & Drawer options for Oven Housings and Larder Ends. We recommend prior to the assembly of housings the installer makes themselves familiar with the door/drawer configuration they are to install. This should alleviate any misalignment which could occur if the installer does not read and digest the diagrams opposite which clearly illustrate the correct positions of all door and drawer configurations.



Please note that many integrated appliances now require very specific drilling to suit their unique hinges, doors should be requested un-drilled to be fitted on site.

For more help on installation & product assembly go to:
www.jjopl.com
view details in Support